

LED Plate Replacement Instructions for AL-3162

DISCONNECT THE POWER AT THE CIRCUIT BREAKER.

1. Remove the shade from the fixture pan. (FIG. 1)
2. Remove the fixture from the ceiling and disconnect its wires from the power supply wires. (FIG. 1)
3. Using a small screwdriver or pen, press down on the connector and simultaneously pull the driver wire out. Repeat for the second connector. (FIG. 2)
4. Remove each of the screws holding the LED driver in place. Set the screws aside.
5. Remove the old LED driver and replace it with the new LED module.
6. Secure the new LED driver in place using the screws that were set aside in step 4.
7. Insert the red driver wire into the connector marked with a "+" . (FIG. 2)
8. Insert the yellow wire to the connector marked with a "-" . (FIG. 2)
9. Reconnect the fixture wires and the power supply wires.
10. Reinstall the shade and frame using the thumb nuts.

RESTORE THE POWER AT THE CIRCUIT BREAKER.

